Pushrods Calibration

Calibration is operated on a flat surface, with scales under the wheels.
Car up, noter the values of each pushrod signal : Vo in mV
Car down on the scales, note the weights : P in kilos, the values of each pushrod signal : V1
For one Pushrod, the gain is : (V1- V0) / P in mV per kilo